

#70122 & #70125 SC10 2wd Rear Bumper & #70152 Mud Flap and Number Plate Kit

What's Included

- #70122 & #70125 Rear Bumper
- 1 - Molded **RPM** Rear Bumper & 4 - 4-40 x 1" buttonhead
- screws.

- #70152 Mud Flap and Number Plate Kit
- 1 - Molded parts tree (containing 1 - Number Plate, 2 - Mud Flap
- Supports & 2 - Screw Supports), 2 - Mud Flaps, 6 - 4-40 x 3/8"
- buttonhead screws & 4 - 4-40 x 1/2" cap screws.

Number Plate Installation: Carefully remove the five molded components from the parts tree using a sharp hobby knife or plastic cutters. The Number Plate is the rectangular piece with two mounting holes. Review the illustration to the right for proper position and placement of the Number Plate on your **RPM** Rear Bumper. Using 2 - 4-40 x 3/8" buttonhead screws, secure the Number Plate to the bumper. *Caution: Do not over tighten the screws!*

Mud Flap Installation: You are supplied with 1 left and 1 right side Mud Flap Support. Your **RPM** Rear Bumper should be off of the truck during mud flap installation. The Mud Flap Supports will fit on the bumper with the **RPM** logo facing rearwards while the bend in the support will go up (see the illustration for reference). You have two options for Mud Flap placement. The illustration shows the Mud Flaps covering the **RPM** logo on the Mud Flap Supports, with the Mud Flaps positioned as far away from the wheel as possible. If you'd like the Mud Flaps closer to the wheels, simply install them on the opposite side of the Mud Flap Supports. Now slip 2 of the 4-40 x 1/2" cap screws through one of the Screw Supports (the slim, rectangular molded part with 2 - 1/8" diameter holes on either end), then through one of the Mud Flaps (orient the **RPM** logo on the Mud Flaps so the logo faces rearwards) and thread both screws into the Mud Flap Support. Once both Mud Flaps are bolted to both Mud Flap Supports, install the Mud Flap assembly on to the bumper. Slip the Mud Flap Supports over the lower posts of your **RPM** rear bumper, then use 2 of the 4-40 x 3/8" buttonhead screws to secure the Mud Flap Supports to your **RPM** Rear Bumper.

The 2 remaining 4-40 x 3/8" buttonhead screws are for use with the optional **RPM #81030 Tail Light Kit** (see below).

RPM Bumper Installation: **RPM** SC10 2wd Rear Bumpers are stock replacement parts. Simply remove your stock SC10 2wd rear bumper and stock mounting screws and replace them with your new **RPM** SC10 2wd Rear Bumper using the 4 supplied 4-40 x 1" buttonhead screws.

RPM #81030 Tail Light Kit (not included): Assemble the individual tail light lenses, housings and mounts according to the instructions provided with the **RPM** Tail Light Kit. Mount the tail light assemblies to your **RPM** SC10 2wd Rear Bumper using the 2 remaining 4-40 x 3/8" buttonhead screws, orienting the tail lights as shown in the illustration. Make sure the number plate sandwiches between the bumper and the right hand tail light assembly as shown in the illustration above.

