

#73240 - LST2 A-arm Adapter Kit **(Must use RPM #73192 or #73195 A-arms)**

Follow all "Assembly" instructions that came with your **RPM** Adjustable Camber A-arms before installing this kit on your LST2. Attach your upper and lower **RPM** A-arms to the bulkhead of the truck. When installing the upright to the A-arms, slide your hinge pin through the upright, followed by one spacer from this kit, and then slide the hinge pin through the A-arm. Install a second spacer on the other side of the A-arm between the upright and the A-arm. Finally, press the hinge pin all the way through the upright. Follow these instructions for both the upper and lower A-arms, using a total of 4 spacers per upright.

Rear Axle Carrier Interference Issues: Some minor filing or grinding of the rear axle carriers may be necessary to achieve full suspension travel. Assemble the rear A-arms to the axle carrier as mentioned above, then move the suspension up and down to see where the axle carriers hit on the upper and lower A-arms. Using a dremel tool or file, remove a minor amount of material from the carrier to allow clearance for the A-arms.