

## #80010 - Pillow Ball Setscrews, Bushings, & Bearing Spacers

**All Vehicles** - There may be small amounts of flashing on the black plastic bushing caps. Please use extreme caution and remove any flashing with a sharp hobby or X-Acto knife before assembly to prevent possible installation problems.

**Traxxas T/E-Maxx** - Your **RPM** Pillow Ball Setscrews and Bushings are stock replacement parts. Simply remove the stock parts and replace them with the new **RPM** pieces. **Do not use the two spacers for your truck.**

**Associated MGT** - During installation of your **RPM** Bearing Carriers, the two small spacers included in this kit *must be placed between* the two bearings. This will prevent the bearings from binding when your wheel is bolted in place. **Important Note:** The **RPM** Pillow Ball Setscrews cannot be used with stock MGT carriers. They can only be used with **RPM Bearing Carriers (#80031, #80032, #80035, & #80038)**. The black plastic bushings will press into the bore of the aluminum setscrews. Press them in before installing the setscrews & bushing into your **RPM** carriers. Do not insert the bushing in the carrier & then try to thread the setscrew into it - the bushing may move & may not seat properly against the pillow ball. Insert your MGT pillow balls in each of the **RPM** bearing carriers followed by the assembled setscrews with the black plastic bushing toward the pillow ball. Finally, please read the caution in the instructions that came with your **RPM** bearing carriers regarding the proper way to install these setscrews.