

**#80302, #80311, #80332 & #80341**  
**Snap-Tite Body Savers**

Slip the base piece (without the logo) through the bottom of the body and snap the top piece (with the logo) in place on top of the body. ***In most cases, the stock body hole diameter is too small and may need to be opened slightly to allow the body saver to fit through the body.*** The two-piece tree is designed for either the antenna hole or a transponder mount (using a 3/16" dia. post).