

#70642 & #70702 - Front & Rear Shock Hoops & Body Mounts for the Axial SCX10

What's Included: 2 - Shock Hoops (front or rear),
2 - Body Mounts & 4 - M2.5 x 12mm buttonhead screws.

Installation: *RPM* Shock Hoops are stock replacement parts and install on the vehicle identically as stock components. Note the orientation of the Body Mount holes on the Shock Hoops. One

side has larger holes than the other (same side as the *RPM* logo). The **larger holes**

should face towards the front for front Shock Hoops and towards the rear for rear Shock Hoops. Slip the two M2.5 x 12mm screws (included)

in through the Shock Hoop and Body Mount, then thread into the opposite side of the Shock Hoop. **Caution: Do not overtighten!**

Set-Up: The three center holes in the Shock Hoops are stock geometry. To **raise** the ride height, thread the upper shock mount into one of the **lower** two screw holes.

Conversely, use the **upper** two screw holes to **lower** the ride height.

