

#81392 - Front Upper & Lower A-arms for the ARRMA Granite, Vorteks, Raider, Fury & Mojave □

What's Included: 2 - Front Upper A-arms, 2 - Front Lower A-arms, 2 - M3 x 12mm Buttonhead □
□ Screws, & 2 - M3 x 20mm Buttonhead Screws.

Installation: *RPM* A-arms are stock replacement parts. Simply remove your stock A-arms and replace them with your new *RPM* versions. However, please be aware of the following considerations:

1) Caution: *RPM* A-arms are asymmetrical! The *RPM* logos on the A-arms must face the front of the vehicle for proper A-arm orientation.

2) Thread the stock camber link setscrew into the *RPM* upper A-arm until it bottoms out. Use caution and do not over-tighten this screw. Afterwards, thread the stock camber link rod end back on to the setscrew. □

3) Replace the stock M3 x 25mm shock mount screws with the included M3 x 20mm Buttonhead screws.

4) The stock M3 x 15mm turnbuckle-to-spindle block screws must be replaced using the included M3 x 12mm screws or interference may occur. Install as shown, using the stock washer. □

Adjustments: Be sure to reset your Camber and Toe angle settings after installation for the best possible performance. *RPM* recommends using a gauge such as our Camber Gauge (*RPM* #70992) and Toe Gauge (*RPM* #70492) for extremely accurate settings.

