

## #73402 - Front Spindle Set for the Losi Super Rock Rey

**What's Included:** 1 - Left Spindle Block, 1 - Right Spindle Block, 2 - Caliper Mounting Plates & 4 - M3 x 8mm Buttonhead Cap Screws.

**Before You Begin:** Disassemble your stock spindle set, retaining the 2 - M3 x 10mm cap head screws that hold the stock caliper mounting plate to the stock spindles. Retain the 4 - M3 x 10mm cap head screws that hold the stock caliper to the caliper mounting plate. These 6 screws will be reused with your **RPM** Spindle Set. □

**Installation: 1)** Clip the Spindles and Caliper Mounting Plates off of their respective trees. Afterwards, bolt the included Caliper Mounting Plates to the Spindles as shown to the right using the stock M3 x 10mm cap head screws. **Caution:** The Caliper Mounting Plates are directional.

**2)** Install the 2 included M3 x 8mm buttonhead screws as shown in the illustration (below left). Do not tighten at this time. Simply get them started and turned in roughly 3/4 of the way.

**3)** Finish installing the **RPM** Spindles on your Super Rock Rey, making sure to install the stock caliper only after the axle has been installed in the Spindle and the brake disk is in place, using the remaining 4 stock M3 x 10mm cap head screws.

**4)** Tighten the M3 x 8mm buttonhead screws once the kingpins have been installed.

**Weight Reduction Tips:** You can reduce unsprung weight by as much as 2 grams simply by replacing all 6 of the stock M3 x 10mm cap head screws with M3 x 8mm buttonhead screws (not included). Since these are non-critical screws, smaller, lighter screws will not affect the strength or durability of the vehicle in any negative way. Alternately, leaving the caliper plates and calipers off entirely will save additional unsprung weight.

