

#81612 - ECX Torment 4x4 Kick Plate & Front Bumper

What's Included: 1 - Front Bumper, 1 - Front Skid Plate, 1 - Kick Plate, 1 - Brace, 5 - M3 x 12mm buttonhead screws, 2 - M3 x 16mm buttonhead screws, 2 - M3 x 25mm buttonhead screws & 4 - 3mm locknuts.

Before You Begin: Remove the stock front bumper, front bumper support and kick plate from your truck. You may discard the four mounting screws for the bumper support but retain the mounting screws for the kick plate. They will be reused.

Assembly: 1) Bolt the Brace to the front differential cover of your truck using 2 of the included M3 x 12mm screws and lock in place with 2 of the included 3mm locknuts (note the orientation of the brace in the illustration at the bottom of this instruction sheet). The screws will slip in through the top of the brace, with the locknuts securing the brace from under the differential cover's mounting flange.

2) Bolt the front bumper to the front skid plate using 3 of the included M3 x 12mm screws.

2a) If you are installing an **RPM** Light Canister Set (**RPM** #80982 or #80983), do so at this time. The Light Canister fits between the bumper and the skid plate.

3) Bolt the Kick Plate to the chassis / front differential using the stock screws removed earlier. Caution: Be sure to orient the aluminum bellcrank posts so they fit in the hex clearance bosses of the **RPM** Kick Plate.

4) Bolt the Front Bumper / Skid Plate / Kick Plate to the **RPM** Brace in the rear two mounting holes of the Skid Plate using the 2 included M3 x 25mm buttonhead screws. Slip the remaining 2 - M3 x 16mm buttonhead screws through the front 2 mounting holes of the Skid Plate and into the Kick Plate. Secure with the remaining 2 - 3mm locknuts.

